

Assembly Instructions



Install one head at a time

1. Remove the 2 bolts / 2 wingnuts that are already attached to the handles for shipping.
2. Slide one head onto one of the handle ends with the bend in the middle facing inward – See Figure 1.
3. Align the hole in the handle with the **bottom** hole in the head.
4. Insert a bolt from in between the handles through the head and handle. See Figure 2 below.
5. Hand-tighten the wingnut onto the bolt. **Do not** over-tighten.
6. Repeat Steps 2 – 5 for the other side.

Questions? Contact us at info@gardengrabx.com

